

Star Beam 7R -Channel Functions (18chs)

No.	Channel	DMX value	Description
1	Pan	0-255	
2	Tilt	0-255	
3	Pan fine	0-255	
4	Tilt fine	0-255	
5	X/Y Speed	0-255	
6	Dimmer	0-255	
7	Strobe	0-2 3-50 51-240 241-255	Off On Slow-Fast On
8	Colorful	0-255	
9	Color Wheel	0 1-7 8-15 16-23 24-31 32-39 40-47 48-55 56-63 64-71 72-79 80-87 88-95 96-103 104-111 112-127 128-190 191-255	White Color1 Color2 Color3 Color4 Color5 Color6 Color7 Color8 Color9 Color10 Color11 Color12 Color13 Color14 No function (Inverted water) Color rotation: Slow-Fast (Downstream) water Color rotation: Slow-Fast
10	Color effect	0-255	

11	Gobo	0	White
		1-7	Gobo1
		8-14	Gobo2
		15-21	Gobo3
		22-28	Gobo4
		29-35	Gobo5
		36-42	Gobo6
		43-49	Gobo7
		50-56	Gobo8
		57-63	Gobo9
		64-70	Gobo10
		71-77	Gobo11
		78-84	Gobo12
		85-91	Gobo13
		92-98	Gobo14
		99-105	Gobo15
		106-112	Gobo16
		113-119	Gobo17
		120-126	Gobo18
		127-190	(Inverted water) Gobo rotation: Slow-Fast
		191-225	(Downstream) water Cobo rotation: Slow-Fast
12	Gobo Shaking	0-191	Slow-Fast
		192-255	White Color
13	Prism1	0-255	
14	Prism 2	0-127	Prism fine
		128-190	Invert: Fast-Slow
		191-255	Veer: Slow-Fast
15	Prism Rotation		
16	Focus	0-255	
17	Lamp control	0-99	No function
		100-105	Lamp OFF
		106-199	No function
		200-205	Lamp ON
		206-255	No function
18	Reset	0-255	

